

Motor Code: — Motor Model: — Serial No: — Tested By: — Test Date: —

INSPECTION CHECKLIST

S.NO	DESCRIPTION	SPECIFICATION	METHOD OF CHECK	OBSERVED	STATUS
1	Spigot Seat	154,90 (0,00/-0,03) mm	OD Snap gauge	—	—
2	Front Mounting Thread	3x M6×1 - 6H, l 18,00 mm	Plug gauge check found OK	—	—
3	Shaft OD Total Runout Wrt Datum B	0,1 mm	Total Indicator Reading	—	—
4	Shaft Front Face to Front Mount Spigot Seating Distance	28,20 ± 0,50 mm	Height Gauge	—	—
5	Shaft Spline	As per Drawing	Master Spline	—	—
6	Dry Leak Test	at Min. 0,2 bar	Pressurised air and foam water	—	—
7	Thermister Fuction	Resistance at room temperature	Resistance meter	—	—
8	Sensor Cable Color Sequence	Pin 1 - Red (Vdd (+5V))	Visual	—	—
9	Sensor Cable Color Sequence	Pin 2 - White (PT 1000 +ve)	Visual	—	—
10	Sensor Cable Color Sequence	Pin 3 - Yellow (Sin output)	Visual	—	—
11	Sensor Cable Color Sequence	Pin 4 - Blue (Cos output)	Visual	—	—
12	Sensor Cable Color Sequence	Pin 5 - Black (Common GND)	Visual	—	—
13	Sensor Cable Color Sequence	Pin 6 - Green (Shield + Wire)	Visual	—	—
14	Motor Length	177,8 (+/- 1,5)	Height Gauge	—	—
15	Motor Weight	14,7 (+/- 0,15)	Weight Scale	—	—
16	Phase Cable Grommet	Manual Assembly	Visual	—	—
17	Terminal Cover	Manual Assembly	Visual	—	—
18	Terminal Cover Assembly Bolts	Manual Assembly	Visual	—	—
19	Phase Cable Assembly Bolts	Manual Assembly	Visual	—	—
20	Visual Defects	Free From Rust, Dust, Physical Damage	Visual	—	—
21	Deviations if any	Connector push mount not provided, push mount cable tie provided as alternative			—

ⓘ This is a system-approved document; signatures are not required.

INSPECTION RESULT: **FAILED**

INSPECTED BY: — INSPECTION DATE: —